CAUTION

Once wireless joy pad mal-function

(LED of main console and joypad keep flashing)

RESET PROCESS:

① **Turn on joypad ⏻ power** → ② **Push Ⓢ 2.4G button** → ③ **Turn on console ⏻ power**

Auto connect after both LED lights flash for 3-5 seconds and off.

CAUTION
- ✻ Unable to connect when low battery (need change new battery)
- ✻ Need 15-20 seconds to re-connect once push Ⓢ 2.4G when playing
- ✻ Auto-off after 1 minute idle (or push ⏻ 20 seconds to turn off)